

SNAPP[®] screen Project Planner

STEP 1: Use the reverse side of this form (or other larger paper if needed) and draw a simple diagram of your project. Include measurements for all sides of every opening being screened. In inches and, round all measurements up 2 inches and to the next full inch. (Example: 36-1/2" would = 39") Add all measurements taken and enter total in the space provided on the reverse side. Add all sections together and enter the TOTAL inches below.

Total inches for all openings being screened divide by 94 = This is the minimum lengths of extrusions required. Add 1 or 2 lengths to total to be safe.

STEP 2: 10 mounting screws are required for each extrusion ordered. Our mounting screws are for wood or composite installations. (You'll need to supply your own screws for installations into other materials) You'll need 1 bag of screws for every 10 extrusions ordered. Always round up.

Lengths of extrusions ordered divide by 10 = Bags of screws needed (always round up to next full bag)

STEP 3: SNAPP[®] screen spline **must** be used when installing screen into the SNAPP[®] screen extrusion. Spline is sold in 10 extrusion rolls. Our standard spline works with our screen as well as all commonly available screen materials. (This would include fiberglass Pool & Patio screen, fiberglass No-See-Um screen, fiberglass window screen and High Clarity screens)

Lengths of extrusions ordered divide by 10 = Rolls of spline needed (always round up to next full roll)

STEP 4: A spline installation tool is required for screen and spline installation. Our tool is sized to fit the SNAPP[®] screen extrusion without damaging screen. Unless there is more than 1 installer, only 1 tool is required. (**NOTE:** All spline tools are not the same and your local home center will not likely have the correct tool)

STEP 5: Screen roll size is based on the largest project opening. Look at your opening measurements and find which is largest. Based on that opening, determine if it's best to order a roll of screen to cover the opening across its "width" (screen running vertically - up and down) or across its "height" (screen running horizontally - from left to right or right to left). The goal here is to use the smallest roll of screen (width wise) that can cover the largest opening and therefore will be able to cover all other smaller openings. Keep in mind that you need a minimum 1" overlap on all sides of each opening for installation ... and it doesn't matter if screen is installed horizontally, vertically, or a combination of both. Screen is available in 100 total foot rolls and normally in width sizes 36", 48", 60", 72", 84", 96", 108", 120", 126" and 144". (See web store for exact availability)

MATERIALS ORDER LIST

Lengths of extrusions: ☐ PVC ☐ Aluminum
☐ Mill ☐ White ☐ Bronze ☐ Black

Bags of mounting screws: (1 bag per 10 extrusions)

Rolls of spline: (1 roll per 10 extrusions)

Spline installation tool:

Screen: (100 total feet per roll) ☐ Pool & Patio ☐ No-See-Um ☐ Super No-See-Um

☐ 36" ☐ 48" ☐ 60" ☐ 72" ☐ 84" ☐ 96" ☐ 108" ☐ 120" ☐ 126" ☐ 144" (Not all widths available)

NEED MORE HELP ?

Go to youtube.com/@snappscreen and watch our video tutorial for this project planner

Complete installation instructions, with videos, are also available at screenporch.com

PLACE ORDERS ON LINE AT: [SHOP.SNAPPSCREEN.COM](https://shop.snappscreen.com)

ScreenPorch.com, Inc. • Northford, CT 06472 • info@screenporch.com
US PATENT: US 8,484,926 • SNAPP is a registered Trademark of 4 Pat, LLC

SIDE 3

TOTAL INCHES: _____

SIDE 2

TOTAL INCHES: _____

SIDE 1

TOTAL INCHES: _____